

GAGNE, INC.

The Light Panel by Porta-Trace

Important Safety Instructions

1. Do not use this equipment with a damaged power cord or if unit has been otherwise damaged until an electrician has examined it.
2. If an extension cord is required be sure to use a cord that is rated for the same or higher amperage than this equipment to prevent overheating. Please arrange cords that they will not be tripped over or pulled.
3. Always unplug equipment from the electrical outlet when not in use. Always unplug by grabbing the power adapter and removing from the outlet, never pull on the cord to remove as it may damage the adapter or outlet.
4. Do not immerse in water. If equipment receives water damage, do not use until inspected by an electrician.

Set Up and Operation

1. The Light Panel is shipped in a protective fabric sleeve.
Always store your Light Panel in this sleeve to keep it safe and scratch-free.
2. Included with The Light Panel are 4 soft adhesive foot pads, which may be mounted in the bottom corners.
3. Remove The Light Panel from box and protective cover.
4. Plug the power adapter into an electrical outlet then plug the adapter into The Light Panel.
5. Touch the On/Off dimmer located in the lower left corner of The Light Panel.
6. Adjust light level by pressing with 5 Levels available: 0%-25%-50%-75%-100%



Maintenance

Clean acrylic surface and aluminum sides with a soft cloth and nonabrasive cleaner such as dish soap. Never apply cleaner directly onto The Light Panel as it may leak into the unit and cause damage.

Warranty

This product is warranted against defects in workmanship and materials for one year after original purchase date to the original purchaser only. If any part of the equipment becomes defective under normal installation and use, it will be repaired or replaced by Seller with no cost provided the equipment within this period. This does not apply to equipment that has been abused, accidents or alterations.